

# AMERICH®



Our boxing process begins with a pallet and box bottom before setting the tub on to the box bottom. Next, we install 3" adhesive runner that serve two purposes;

1. To elevate the bathtub and act as shock absorbers if the pallet were to be dropped (shown on image to the left) or mishandled.
2. We use the adhesive runner as spacers against the feet so the tub does not slide within the box during transportation (shown on image to the right)



- The box top is then added along with accordion cardboard spacers over the tub deck for protection against carrier stacking and to hold the tub in place against the bottom 3" runners. (shown on left image)
- Side accordion spacers are added for 30"-32" bathtubs along the sides. (not shown)
- Staples are added to secure the deck accordion pieces as well as to close the top flaps of the box
- Straps are then done on both the box and box to pallet separately

